

TRX baterie Acer/ 5200 mAh/ Aspire 4250/ 4551/ 4738/ 4741/ 4551G/ 4771G/ 5551G/ 5741G/ 5750/ 7251/ Acer AS10D3E/ AS10D41

cena vč DPH: 1033 Kč

cena bez DPH: 854 Kč

Kód zboží (ID): 4943151

PN: TRX-AS10D31-H

Záruka: 24 měsíců



TRX AS10D31 H

ZÁKLADNÍ SPECIFIKACE

Technologie baterie: Li-Ion

Napětí: 10,8 V, 11,1V

Kapacita: 5200 mAh

Baterie je záměnná s těmito produktovými čísly:

AS10D, AS10D3E, AS10D31, AS10D41, AS10D5E, AS10D51, AS10D61, AS10D7E,
AS10D71, AS10D73, AS10D75, AS10D81

BT.0060G.001, BT.00603.111, BT.00603.117, BT.00603.124, BT.00603.129,
BT.00604.049, BT.00605.062, BT.00605.065, BT.00605.072, BT.00606.008,
BT.00607.125, BT.00607.126, BT.00607.127, BT.00607.130,

LC.BTP0A.015, LC.BTP00.123, 31NR19/65-2, 31CR19/652, 31CR19/65-2,
31CR19/66-2, AK.006BT.075, AK.006BT.080

Baterie je kompatibilní s těmito modely:

ACER Aspire AS5253 Aspire E1 Aspire E1-421 Aspire E1-431 Aspire E1-471 Aspire

E1-471G Aspire E1-521 Aspire E1-531 Aspire E1-571 Aspire V3 Aspire V3-471 Aspire V3-471G Aspire V3-551 Aspire V3-551G Aspire V3-571 Aspire V3-571G Aspire V3-731 Aspire V3-771 Aspire V3-771G Aspire 4250 Aspire 4250G Aspire 4250Z Aspire 4251 Aspire 4251G Aspire 4251Z Aspire 4252 Aspire 4252G Aspire 4252Z Aspire 4253 Aspire 4253G Aspire 4333 Aspire 4339 Aspire 4349 Aspire 4350 Aspire 4350G Aspire 4352 Aspire 4551 Aspire 4551G Aspire 4551P Aspire 4552 Aspire 4552G Aspire 4552-5078 Aspire 4560 Aspire 4560G Aspire 4733Z Aspire 4738 Aspire 4738G Aspire 4738Z Aspire 4738ZG Aspire 4739 Aspire 4739Z Aspire 4741 Aspire 4741G Aspire 4741Z Aspire 4741ZG Aspire 4743 Aspire 4743G Aspire 4743Z Aspire 4743ZG Aspire 4749 Aspire 4749Z Aspire 4750 Aspire 4750G Aspire 4750Z Aspire 4750ZG Aspire 4752 Aspire 4752G Aspire 4752Z Aspire 4752ZG Aspire 4755 Aspire 4755G Aspire 4755ZG Aspire 4771 Aspire 4771G Aspire 4771Z Aspire 5250 Aspire 5251 Aspire 5252 Aspire 5253 Aspire 5253G Aspire 5333 Aspire 5336 Aspire 5342 Aspire 5349 Aspire 5350 Aspire 5551 Aspire 5551G Aspire 5552 Aspire 5552G Aspire 5560G Aspire 5733 Aspire 5733Z Aspire 5736 Aspire 5736G Aspire 5736Z Aspire 5736ZG Aspire 5741 Aspire 5741G Aspire 5741Z Aspire 5741ZG Aspire 5742 Aspire 5742G Aspire 5742Z Aspire 5742ZG Aspire 5749 Aspire 5749Z Aspire 5750 Aspire 5750G Aspire 5750TG Aspire 5750Z Aspire 5750ZG Aspire 5755 Aspire 5755G Aspire 5755Z Aspire 5755ZG Aspire 7251 Aspire 7551 Aspire 7551G Aspire 7551Z Aspire 7551ZG Aspire 7552G Aspire 7560 Aspire 7560G Aspire 7741 Aspire 7741G Aspire 7741Z Aspire 7741ZG Aspire 7750 Aspire 7750G Aspire 7750Z Aspire 7750ZG TravelMate P243 TravelMate P243-M TravelMate P243-MG TravelMate P453 Travelmate P453-M TravelMate P453-MG TravelMate TM5740 TravelMate TM5742 TravelMate 4370 TravelMate 4740 TravelMate 4740G TravelMate 4740Z TravelMate 4740ZG TravelMate 4750 TravelMate 4750G TravelMate 4750Z TravelMate 4750ZG TravelMate 5335 TravelMate 5335G TravelMate 5335Z TravelMate 5340 TravelMate 5340G Travelmate 5344 TravelMate 5360 TravelMate 5360G TravelMate 5542 TravelMate 5542G Travelmate 5735 TravelMate 5735G TravelMate 5735Z Travelmate 5735ZG TravelMate 5740 TravelMate 5740G Travelmate 5740Z TravelMate 5740ZG TravelMate 5742 TravelMate 5742G TravelMate 5742Z TravelMate 5742ZG TravelMate 5744 TravelMate 5744G TravelMate 5744Z TravelMate 5760 Travelmate 5760G TravelMate 6495 TravelMate 6495G TravelMate 6495T TravelMate 6495TG TravelMate 6595 TravelMate 6595G TravelMate 6595T TravelMate 6595TG TravelMate 7340 TravelMate 7740 TravelMate 7740G TravelMate 7740Z TravelMate 7740ZG TravelMate 7750G TravelMate 7750Z Travelmate 7750ZG TravelMate 8472 TravelMate 8472 HF TravelMate 8472G TravelMate 8472G HF TravelMate 8472T TravelMate 8472T HF TravelMate 8472TG TravelMate 8472TG HF TravelMate 8473 TravelMate 8473G TravelMate 8473T TravelMate 8473TG TravelMate 8572 TravelMate 8572G TravelMate 8572T TravelMate 8572T HF TravelMate 8572TG TravelMate 8573 TravelMate 8573G TravelMate 8573T TravelMate 8573TG EMACHINES D440, D442, D443, D582, D642, D728, D730, D732, E440, E442, E529, E640, E642, E729, E732, G640, G730 GATEWAY NS41I, NS51I, NV49C, NV49C13C, NV49xx, NV50A, NV51B, NV53, NV53A, NV53A11u, NV55C, NV59C, NV73A, NV79, NV79C PACKARD BELL EasyNote LS11, EasyNote LS13, EasyNote LS44, EasyNote LV11, EasyNote LV44, EasyNote NM85, EasyNote NM86, EasyNote NM87, EasyNote NM98, EasyNote TE11, EasyNote TK36, EasyNote TK37, EasyNote TK81, EasyNote TK83, EasyNote TK85, EasyNote TK87, EasyNote TM98, EasyNote TS11, EasyNote TS13, EasyNote TV11, EasyNote TV43, EasyNote TV43HC, EasyNote TV44

TRX AS10D31 H

<p>ZÁKLADNÍ SPECIFIKACE</p>

<p>Technologie baterie: Li-Ion</p>

<p>Napětí: 10,8 V, 11,1V</p>

<p>Kapacita: 5200 mAh</p>

<p>Baterie je záměnná s těmito produktovými čísly:</p>

<p>AS10D, AS10D3E, AS10D31, AS10D41, AS10D5E, AS10D51, AS10D61, AS10D7E, AS10D71, AS10D73, AS10D75, AS10D81</p>

<p>BT.0060G.001, BT.00603.111, BT.00603.117, BT.00603.124, BT.00603.129, BT.00604.049, BT.00605.062, BT.00605.065, BT.00605.072, BT.00606.008, BT.00607.125, BT.00607.126, BT.00607.127, BT.00607.130,</p>

<p>LC.BTP0A.015, LC.BTP00.123, 3INR19/65-2, 31CR19/652, 31CR19/65-2, 31CR19/66-2, AK.006BT.075, AK.006BT.080</p>

<p>Baterie je kompatibilní s těmito modely:</p>

<p>ACER

Aspire AS5253

Aspire E1

Aspire E1-421

Aspire E1-431

Aspire E1-471

Aspire E1-471G

Aspire E1-521

Aspire E1-531

Aspire E1-571

Aspire V3

Aspire V3-471

Aspire V3-471G

Aspire V3-551

Aspire V3-551G

Aspire V3-571

Aspire V3-571G

Aspire V3-731

Aspire V3-771

Aspire V3-771G

Aspire 4250

Aspire 4250G

Aspire 4250Z

Aspire 4251

Aspire 4251G

Aspire 4251Z

Aspire 4252

Aspire 4252G

Aspire 4252Z

Aspire 4253

Aspire 4253G

Aspire 4333

Aspire 4339

Aspire 4349

Aspire 4350

Aspire 4350G
Aspire 4352
Aspire 4551
Aspire 4551G
Aspire 4551P
Aspire 4552
Aspire 4552G
Aspire 4552-5078
Aspire 4560
Aspire 4560G
Aspire 4733Z
Aspire 4738
Aspire 4738G
Aspire 4738Z
Aspire 4738ZG
Aspire 4739
Aspire 4739Z
Aspire 4741
Aspire 4741G
Aspire 4741Z
Aspire 4741ZG
Aspire 4743
Aspire 4743G
Aspire 4743Z
Aspire 4743ZG
Aspire 4749
Aspire 4749Z
Aspire 4750
Aspire 4750G
Aspire 4750Z
Aspire 4750ZG
Aspire 4752
Aspire 4752G
Aspire 4752Z
Aspire 4752ZG
Aspire 4755
Aspire 4755G
Aspire 4755ZG
Aspire 4771
Aspire 4771G
Aspire 4771Z
Aspire 5250
Aspire 5251
Aspire 5252
Aspire 5253
Aspire 5253G
Aspire 5333
Aspire 5336
Aspire 5342

Aspire 5349
Aspire 5350
Aspire 5551
Aspire 5551G
Aspire 5552
Aspire 5552G
Aspire 5560G
Aspire 5733
Aspire 5733Z
Aspire 5736
Aspire 5736G
Aspire 5736Z
Aspire 5736ZG
Aspire 5741
Aspire 5741G
Aspire 5741Z
Aspire 5741ZG
Aspire 5742
Aspire 5742G
Aspire 5742Z
Aspire 5742ZG
Aspire 5749
Aspire 5749Z
Aspire 5750
Aspire 5750G
Aspire 5750TG
Aspire 5750Z
Aspire 5750ZG
Aspire 5755
Aspire 5755G
Aspire 5755Z
Aspire 5755ZG
Aspire 7251
Aspire 7551
Aspire 7551G
Aspire 7551Z
Aspire 7551ZG
Aspire 7552G
Aspire 7560
Aspire 7560G
Aspire 7741
Aspire 7741G
Aspire 7741Z
Aspire 7741ZG
Aspire 7750
Aspire 7750G
Aspire 7750Z
Aspire 7750ZG
TravelMate P243

TravelMate P243-M
TravelMate P243-MG
TravelMate P453
Travelmate P453-M
TravelMate P453-MG
TravelMate TM5740
TravelMate TM5742
TravelMate 4370
TravelMate 4740
TravelMate 4740G
TravelMate 4740Z
TravelMate 4740ZG
TravelMate 4750
TravelMate 4750G
TravelMate 4750Z
TravelMate 4750ZG
TravelMate 5335
TravelMate 5335G
TravelMate 5335Z
TravelMate 5340
TravelMate 5340G
Travelmate 5344
TravelMate 5360
TravelMate 5360G
TravelMate 5542
TravelMate 5542G
Travelmate 5735
TravelMate 5735G
TravelMate 5735Z
Travelmate 5735ZG
TravelMate 5740
TravelMate 5740G
Travelmate 5740Z
TravelMate 5740ZG
TravelMate 5742
TravelMate 5742G
TravelMate 5742Z
TravelMate 5742ZG
TravelMate 5744
TravelMate 5744G
TravelMate 5744Z
TravelMate 5760
Travelmate 5760G
TravelMate 6495
TravelMate 6495G
TravelMate 6495T
TravelMate 6495TG
TravelMate 6595
TravelMate 6595G

TravelMate 6595T
TravelMate 6595TG
TravelMate 7340
TravelMate 7740
TravelMate 7740G
TravelMate 7740Z
TravelMate 7740ZG
TravelMate 7750G
TravelMate 7750Z
Travelmate 7750ZG
TravelMate 8472
TravelMate 8472 HF
TravelMate 8472G
TravelMate 8472G HF
TravelMate 8472T
TravelMate 8472T HF
TravelMate 8472TG
TravelMate 8472TG HF
TravelMate 8473
TravelMate 8473G
TravelMate 8473T
TravelMate 8473TG
TravelMate 8572
TravelMate 8572G
TravelMate 8572T
TravelMate 8572T HF
TravelMate 8572TG
TravelMate 8573
TravelMate 8573G
TravelMate 8573T
TravelMate 8573TG

EMACHINES

D440, D442, D443, D582, D642, D728, D730, D732, E440, E442, E529, E640, E642, E729, E732, G640, G730

GATEWAY

NS41I, NS51I, NV49C, NV49C13C, NV49xx, NV50A, NV51B, NV53, NV53A, NV53A11u, NV55C, NV59C, NV73A, NV79, NV79C

PACKARD BELL

EasyNote LS11, EasyNote LS13, EasyNote LS44, EasyNote LV11, EasyNote LV44, EasyNote NM85, EasyNote NM86, EasyNote NM87, EasyNote NM98, EasyNote TE11, EasyNote TK36, EasyNote TK37, EasyNote TK81, EasyNote TK83, EasyNote TK85, EasyNote TK87, EasyNote TM98, EasyNote TS11, EasyNote TS13, EasyNote TV11, EasyNote TV43, EasyNote TV43HC, EasyNote TV44