

# TRX baterie Acer/ 7800 mAh/ Aspire 4250/ 4551/ 4738/ 4741/ 4551G/ 4771G/ 5551G/ 5741G/ 5750/ 7251/ Acer AS10D3E/ AS10D41

**cena vč DPH:** **1415 Kč**

cena bez DPH: 1170 Kč

**Kód zboží (ID):** 4943152

**PN:** TRX-AS10D31-XH

**Záruka:** 24 měsíců



TRX AS10D31 XH

## ZÁKLADNÍ SPECIFIKACE

Technologie baterie: Li-Ion

Napětí: 10,8 V, 11,1V

Kapacita: 7800 mAh

Baterie je záměnná s těmito produktovými čísly:

AS10D, AS10D3E, AS10D31, AS10D41, AS10D5E, AS10D51, AS10D61, AS10D7E,  
AS10D71, AS10D73, AS10D75, AS10D81

BT.0060G.001, BT.00603.111, BT.00603.117, BT.00603.124, BT.00603.129,  
BT.00604.049, BT.00605.062, BT.00605.065, BT.00605.072, BT.00606.008,  
BT.00607.125, BT.00607.126, BT.00607.127, BT.00607.130

LC.BTP0A.015, LC.BTP00.123, 31NR19/65-2, 31CR19/652, 31CR19/65-2,  
31CR19/66-2, AK.006BT.075, AK.006BT.080

Baterie je kompatibilní s těmito modely:

ACER Aspire AS5253 Aspire E1 Aspire E1-421 Aspire E1-431 Aspire E1-471 Aspire

E1-471G Aspire E1-521 Aspire E1-531 Aspire E1-571 Aspire V3 Aspire V3-471 Aspire V3-471G Aspire V3-551 Aspire V3-551G Aspire V3-571 Aspire V3-571G Aspire V3-731 Aspire V3-771 Aspire V3-771G Aspire 4250 Aspire 4250G Aspire 4250Z Aspire 4251 Aspire 4251G Aspire 4251Z Aspire 4252 Aspire 4252G Aspire 4252Z Aspire 4253 Aspire 4253G Aspire 4333 Aspire 4339 Aspire 4349 Aspire 4350 Aspire 4350G Aspire 4352 Aspire 4551 Aspire 4551G Aspire 4551P Aspire 4552 Aspire 4552G Aspire 4552-5078 Aspire 4560 Aspire 4560G Aspire 4733Z Aspire 4738 Aspire 4738G Aspire 4738Z Aspire 4738ZG Aspire 4739 Aspire 4739Z Aspire 4741 Aspire 4741G Aspire 4741Z Aspire 4741ZG Aspire 4743 Aspire 4743G Aspire 4743Z Aspire 4743ZG Aspire 4749 Aspire 4749Z Aspire 4750 Aspire 4750G Aspire 4750Z Aspire 4750ZG Aspire 4752 Aspire 4752G Aspire 4752Z Aspire 4752ZG Aspire 4755 Aspire 4755G Aspire 4755ZG Aspire 4771 Aspire 4771G Aspire 4771Z Aspire 5250 Aspire 5251 Aspire 5252 Aspire 5253 Aspire 5253G Aspire 5333 Aspire 5336 Aspire 5342 Aspire 5349 Aspire 5350 Aspire 5551 Aspire 5551G Aspire 5552 Aspire 5552G Aspire 5560G Aspire 5733 Aspire 5733Z Aspire 5736 Aspire 5736G Aspire 5736Z Aspire 5736ZG Aspire 5741 Aspire 5741G Aspire 5741Z Aspire 5741ZG Aspire 5742 Aspire 5742G Aspire 5742Z Aspire 5742ZG Aspire 5749 Aspire 5749Z Aspire 5750 Aspire 5750G Aspire 5750TG Aspire 5750Z Aspire 5750ZG Aspire 5755 Aspire 5755G Aspire 5755Z Aspire 5755ZG Aspire 7251 Aspire 7551 Aspire 7551G Aspire 7551Z Aspire 7551ZG Aspire 7552G Aspire 7560 Aspire 7560G Aspire 7741 Aspire 7741G Aspire 7741Z Aspire 7741ZG Aspire 7750 Aspire 7750G Aspire 7750Z Aspire 7750ZG TravelMate P243 TravelMate P243-M TravelMate P243-MG TravelMate P453 Travelmate P453-M TravelMate P453-MG TravelMate TM5740 TravelMate TM5742 TravelMate 4370 TravelMate 4740 TravelMate 4740G TravelMate 4740Z TravelMate 4740ZG TravelMate 4750 TravelMate 4750G TravelMate 4750Z TravelMate 4750ZG TravelMate 5335 TravelMate 5335G TravelMate 5335Z TravelMate 5340 TravelMate 5340G Travelmate 5344 TravelMate 5360 TravelMate 5360G TravelMate 5542 TravelMate 5542G Travelmate 5735 TravelMate 5735G TravelMate 5735Z Travelmate 5735ZG TravelMate 5740 TravelMate 5740G Travelmate 5740Z TravelMate 5740ZG TravelMate 5742 TravelMate 5742G TravelMate 5742Z TravelMate 5742ZG TravelMate 5744 TravelMate 5744G TravelMate 5744Z TravelMate 5760 Travelmate 5760G TravelMate 6495 TravelMate 6495G TravelMate 6495T TravelMate 6495TG TravelMate 6595 TravelMate 6595G TravelMate 6595T TravelMate 6595TG TravelMate 7340 TravelMate 7740 TravelMate 7740G TravelMate 7740Z TravelMate 7740ZG TravelMate 7750G TravelMate 7750Z Travelmate 7750ZG TravelMate 8472 TravelMate 8472 HF TravelMate 8472G TravelMate 8472G HF TravelMate 8472T TravelMate 8472T HF TravelMate 8472TG TravelMate 8472TG HF TravelMate 8473 TravelMate 8473G TravelMate 8473T TravelMate 8473TG TravelMate 8572 TravelMate 8572G TravelMate 8572T TravelMate 8572T HF TravelMate 8572TG TravelMate 8573 TravelMate 8573G TravelMate 8573T TravelMate 8573TG EMACHINES D440, D442, D443, D582, D642, D728, D730, D732, E440, E442, E529, E640, E642, E729, E732, G640, G730 GATEWAY NS41I, NS51I, NV49C, NV49C13C, NV49xx, NV50A, NV51B, NV53, NV53A, NV53A11u, NV55C, NV59C NV73A, NV79, NV79C PACKARD BELL EasyNote LS11, EasyNote LS13, EasyNote LS44, EasyNote LV11, EasyNote LV44, EasyNote NM85, EasyNote NM86, EasyNote NM87, EasyNote NM98, EasyNote TE11, EasyNote TK36, EasyNote TK37, EasyNote TK81, EasyNote TK83, EasyNote TK85, EasyNote TK87, EasyNote TM98, EasyNote TS11, EasyNote TS13, EasyNote TV11, EasyNote TV43, EasyNote TV43HC, EasyNote TV44

**<b>TRX AS10D31 XH</b>**

**<p><b>ZÁKLADNÍ SPECIFIKACE</b></p>**

**<p><b>Technologie baterie:</b> Li-Ion</p>**

**<p><b>Napětí:</b> 10,8 V, 11,1V</p>**

**<p><b>Kapacita:</b> 7800 mAh</p>**

**<p><b>Baterie je záměnná s těmito produktovými čísly:</b></p>**

**<p>AS10D, AS10D3E, AS10D31, AS10D41, AS10D5E, AS10D51, AS10D61, AS10D7E, AS10D71, AS10D73, AS10D75, AS10D81</p>**

**<p>BT.0060G.001, BT.00603.111, BT.00603.117, BT.00603.124, BT.00603.129, BT.00604.049, BT.00605.062, BT.00605.065, BT.00605.072, BT.00606.008, BT.00607.125, BT.00607.126, BT.00607.127, BT.00607.130</p>**

**<p>LC.BTP0A.015, LC.BTP00.123, 3INR19/65-2, 31CR19/652, 31CR19/65-2, 31CR19/66-2, AK.006BT.075, AK.006BT.080</p>**

**<p>**

**<b>Baterie je kompatibilní s těmito modely:</b></p>**

**<p>ACER**

**Aspire AS5253**

**Aspire E1**

**Aspire E1-421**

**Aspire E1-431**

**Aspire E1-471**

**Aspire E1-471G**

**Aspire E1-521**

**Aspire E1-531**

**Aspire E1-571**

**Aspire V3**

**Aspire V3-471**

**Aspire V3-471G**

**Aspire V3-551**

**Aspire V3-551G**

**Aspire V3-571**

**Aspire V3-571G**

**Aspire V3-731**

**Aspire V3-771**

**Aspire V3-771G**

**Aspire 4250**

**Aspire 4250G**

**Aspire 4250Z**

**Aspire 4251**

**Aspire 4251G**

**Aspire 4251Z**

**Aspire 4252**

**Aspire 4252G**

**Aspire 4252Z**

**Aspire 4253**

**Aspire 4253G**

**Aspire 4333**

**Aspire 4339**

**Aspire 4349**

Aspire 4350  
Aspire 4350G  
Aspire 4352  
Aspire 4551  
Aspire 4551G  
Aspire 4551P  
Aspire 4552  
Aspire 4552G  
Aspire 4552-5078  
Aspire 4560  
Aspire 4560G  
Aspire 4733Z  
Aspire 4738  
Aspire 4738G  
Aspire 4738Z  
Aspire 4738ZG  
Aspire 4739  
Aspire 4739Z  
Aspire 4741  
Aspire 4741G  
Aspire 4741Z  
Aspire 4741ZG  
Aspire 4743  
Aspire 4743G  
Aspire 4743Z  
Aspire 4743ZG  
Aspire 4749  
Aspire 4749Z  
Aspire 4750  
Aspire 4750G  
Aspire 4750Z  
Aspire 4750ZG  
Aspire 4752  
Aspire 4752G  
Aspire 4752Z  
Aspire 4752ZG  
Aspire 4755  
Aspire 4755G  
Aspire 4755ZG  
Aspire 4771  
Aspire 4771G  
Aspire 4771Z  
Aspire 5250  
Aspire 5251  
Aspire 5252  
Aspire 5253  
Aspire 5253G  
Aspire 5333  
Aspire 5336

Aspire 5342  
Aspire 5349  
Aspire 5350  
Aspire 5551  
Aspire 5551G  
Aspire 5552  
Aspire 5552G  
Aspire 5560G  
Aspire 5733  
Aspire 5733Z  
Aspire 5736  
Aspire 5736G  
Aspire 5736Z  
Aspire 5736ZG  
Aspire 5741  
Aspire 5741G  
Aspire 5741Z  
Aspire 5741ZG  
Aspire 5742  
Aspire 5742G  
Aspire 5742Z  
Aspire 5742ZG  
Aspire 5749  
Aspire 5749Z  
Aspire 5750  
Aspire 5750G  
Aspire 5750TG  
Aspire 5750Z  
Aspire 5750ZG  
Aspire 5755  
Aspire 5755G  
Aspire 5755Z  
Aspire 5755ZG  
Aspire 7251  
Aspire 7551  
Aspire 7551G  
Aspire 7551Z  
Aspire 7551ZG  
Aspire 7552G  
Aspire 7560  
Aspire 7560G  
Aspire 7741  
Aspire 7741G  
Aspire 7741Z  
Aspire 7741ZG  
Aspire 7750  
Aspire 7750G  
Aspire 7750Z  
Aspire 7750ZG

TravelMate P243  
TravelMate P243-M  
TravelMate P243-MG  
TravelMate P453  
Travelmate P453-M  
TravelMate P453-MG  
TravelMate TM5740  
TravelMate TM5742  
TravelMate 4370  
TravelMate 4740  
TravelMate 4740G  
TravelMate 4740Z  
TravelMate 4740ZG  
TravelMate 4750  
TravelMate 4750G  
TravelMate 4750Z  
TravelMate 4750ZG  
TravelMate 5335  
TravelMate 5335G  
TravelMate 5335Z  
TravelMate 5340  
TravelMate 5340G  
Travelmate 5344  
TravelMate 5360  
TravelMate 5360G  
TravelMate 5542  
TravelMate 5542G  
Travelmate 5735  
TravelMate 5735G  
TravelMate 5735Z  
Travelmate 5735ZG  
TravelMate 5740  
TravelMate 5740G  
Travelmate 5740Z  
TravelMate 5740ZG  
TravelMate 5742  
TravelMate 5742G  
TravelMate 5742Z  
TravelMate 5742ZG  
TravelMate 5744  
TravelMate 5744G  
TravelMate 5744Z  
TravelMate 5760  
Travelmate 5760G  
TravelMate 6495  
TravelMate 6495G  
TravelMate 6495T  
TravelMate 6495TG  
TravelMate 6595

TravelMate 6595G  
TravelMate 6595T  
TravelMate 6595TG  
TravelMate 7340  
TravelMate 7740  
TravelMate 7740G  
TravelMate 7740Z  
TravelMate 7740ZG  
TravelMate 7750G  
TravelMate 7750Z  
Travelmate 7750ZG  
TravelMate 8472  
TravelMate 8472 HF  
TravelMate 8472G  
TravelMate 8472G HF  
TravelMate 8472T  
TravelMate 8472T HF  
TravelMate 8472TG  
TravelMate 8472TG HF  
TravelMate 8473  
TravelMate 8473G  
TravelMate 8473T  
TravelMate 8473TG  
TravelMate 8572  
TravelMate 8572G  
TravelMate 8572T  
TravelMate 8572T HF  
TravelMate 8572TG  
TravelMate 8573  
TravelMate 8573G  
TravelMate 8573T  
TravelMate 8573TG

#### EMACHINES

D440, D442, D443, D582, D642, D728, D730, D732, E440, E442, E529, E640, E642, E729, E732, G640, G730

#### GATEWAY

NS41I, NS51I, NV49C, NV49C13C, NV49xx, NV50A, NV51B, NV53, NV53A, NV53A11u, NV55C, NV59C NV73A, NV79, NV79C

#### PACKARD BELL

EasyNote LS11, EasyNote LS13, EasyNote LS44, EasyNote LV11, EasyNote LV44, EasyNote NM85, EasyNote NM86, EasyNote NM87, EasyNote NM98, EasyNote TE11, EasyNote TK36, EasyNote TK37, EasyNote TK81, EasyNote TK83, EasyNote TK85, EasyNote TK87, EasyNote TM98, EasyNote TS11, EasyNote TS13, EasyNote TV11, EasyNote TV43, EasyNote TV43HC, EasyNote TV44