

TRX baterie Canon/ 2000 mAh/ BP-511/ pro EOS D30/ D60/ 10D/ 20D/ 30D/ 40D/ 50D/ 5D DM-MVX1i/ DM-MV30/ neoriginální

cena vč DPH: **344 Kč**

cena bez DPH: 284 Kč

Kód zboží (ID): 4951068

PN: TRX-BP-511

Záruka: 24 měsíců



TRX baterie pro Canon 2000 mAh

Kompatibilní baterie pro videokamery a fotoaparáty Canon.

ZÁKLADNÍ SPECIFIKACE

Kapacita: 2000 mAh

Technologie baterie: Li-iontová

Nahrazuje baterie: Canon BP-508, BP-511, BP-511A, BP-512, BP-514, BP-522, BP-535, PC511, VCN009

Pro videokamery Canon DM-MVX1i, DM-MV100X, DM-MV100Xi, DM-MV30, DM-MV400, DM-MV430, DM-MV450, FVM1, FVM10, FV10, FV100, FV2, FV20, FV200, FV30, FV300, FV40, FV400, FV50, IXY DVM, MVX100i, MVX150i Optura 10, MVX2i, MVX3i, MV30i, MV300, MV300i, MV400i, MV430i, MV430IMC, MV450i, MV500, MV500i, MV530i, MV550i, MV600, MV600i, MV630i, MV650i, MV700, MV700i, MV730i, MV750i, Optura Pi, Optura Xi, Optura 100MC, Optura 20, Optura 200MC, Optura 50MC, PV130, ZR10

Pro fotoaparáty Canon EOS Digital Rebel, EOS D30, EOS D60, EOS Kiss Digital, EOS 10D, EOS 20D, EOS 20Da, EOS 30D, EOS 300D, EOS 40D, EOS 5D, EOS 50D, Media Storage M30, Media Storage M80, PowerShot G1, PowerShot G2, PowerShot G3, PowerShot G5, PowerShot G6, PowerShot Pro 1, PowerShot Pro 70, PowerShot Pro

90, PowerShot Pro 90 IS

TRX baterie pro Canon 2000 mAh

Kompatibilní baterie pro videokamery a fotoaparáty Canon.

ZÁKLADNÍ SPECIFIKACE

Kapacita: 2000 mAh

Technologie baterie: Li-iontová

Nahrazuje baterie: Canon BP-508, BP-511, BP-511A, BP-512, BP-514, BP-522, BP-535, PC511, VCN009

Pro videokamery

Canon DM-MVX1i, DM-MV100X, DM-MV100Xi, DM-MV30, DM-MV400, DM-MV430, DM-MV450, FVM1, FVM10, FV10, FV100, FV2, FV20, FV200, FV30, FV300, FV40, FV400, FV50, IXY DVM, MVX100i, MVX150i Optura 10, MVX2i, MVX3i, MV30i, MV300, MV300i, MV400i, MV430i, MV430IMC, MV450i, MV500, MV500i, MV530i, MV550i, MV600, MV600i, MV630i, MV650i, MV700, MV700i, MV730i, MV750i, Optura Pi, Optura Xi, Optura 100MC, Optura 20, Optura 200MC, Optura 50MC, PV130, ZR10

Pro fotoaparáty

Canon EOS Digital Rebel, EOS D30, EOS D60, EOS Kiss Digital, EOS 10D, EOS 20D, EOS 20Da, EOS 30D, EOS 300D, EOS 40D, EOS 5D, EOS 50D, Media Storage M30, Media Storage M80, PowerShot G1, PowerShot G2, PowerShot G3, PowerShot G5, PowerShot G6, PowerShot Pro 1, PowerShot Pro 70, PowerShot Pro 90, PowerShot Pro 90 IS