

TRX baterie Panasonic/ 940 mAh/ pro CGA-S009/ DMW-BCF10/ DMW-BCF10E/ DMW-BCF10GK/ CGA-S/ 106C/ neoriginální

cena vč DPH: **429 Kč**

cena bez DPH: 355 Kč

Kód zboží (ID): 4951087

PN: TRX-CGA-S009

Záruka: 24 měsíců



TRX pro Panasonic 940 mAh

Kompatibilní baterie pro fotoaparáty Panasonic.

ZÁKLADNÍ SPECIFIKACE

Kapacita: 940 mAh

Technologie baterie: Li-iontová

Nahrazuje baterie: CGA-S009, DMW-BCF10, DMW-BCF10E, DMW-BCF10GK, CGA-S/106C

Pro fotoaparáty: Panasonic Lumix DMC-FH1, DMC-FH1GK, DMC-FH20, DMC-FH20K, DMC-FH22, DMC-FH22GK, DMC-FH3, DMC-FH3GK, DMC-FP8, DMC-FP8A, DMC-FP8G, DMC-FP8GK, DMC-FP8K, DMC-FP8N, DMC-FP8P, DMC-FP8R, DMC-FP8S, DMC-FP8V, DMC-FS10, DMC-FS11, DMC-FS12, DMC-FS12GK, DMC-FS15, DMC-FS15GK, DMC-FS25, DMC-FS25GK, DMC-FS30, DMC-FS33, DMC-FS4, DMC-FS42, DMC-FS6, DMC-FS6GK, DMC-FS62, DMC-FS7, DMC-FS7GK, DMC-FS9, DMC-FT1, DMC-FT2, DMC-FT2A, DMC-FT2D, DMC-FT2S, DMC-FT3, DMC-FT3A, DMC-FT3D, DMC-FT3R, DMC-FT3S, DMC-FT4, DMC-FT4A, DMC-FT4D, DMC-FT4K, DMC-FT4S, DMC-FX40, DMC-FX48, DMC-FX48GK, DMC-FX550, DMC-FX580, DMC-FX580GK, DMC-FX60, DMC-FX60A, DMC-FX60K, DMC-FX60N, DMC-FX60P, DMC-FX60S, DMC-FX60V, DMC-FX65, DMC-FX65A, DMC-FX65GK, DMC-FX65K, DMC-FX65N, DMC-FX65P, DMC-FX65S, DMC-FX65V, DMC-FX66, DMC-FX66A, DMC-FX66N, DMC-FX66P, DMC-FX66S, DMC-FX66V, DMC-FX68

DMC-FX70, DMC-FX70A, DMC-FX70K, DMC-FX70N, DMC-FX70P, DMC-FX70S, DMC-FX70V, DMC-FX700GK, DMC-FX700K, DMC-FX700S, DMC-FX75, DMC-FX75GK, DMC-FX75K, DMC-FX75N, DMC-FX75P, DMC-FX75S, DMC-FX75V DMC-F2, DMC-F3, DMC-F3K, DMC-F3P, DMC-F3S DMC-TS1, DMC-TS2, DMC-TS3A, DMC-TS3D, DMC-TS3R, DMC-TS3S, DMC-TS4, DMC-TS4A, DMC-TS4D, DMC-TS4K, DMC-TS4S

TRX pro Panasonic 940 mAh

<p>Kompatibilní baterie pro fotoaparáty Panasonic.</p>

<p>ZÁKLADNÍ SPECIFIKACE</p>

<p>Kapacita: 940 mAh</p>

<p>Technologie baterie: Li-iontová</p>

<p>Nahrazuje baterie: CGA-S009, DMW-BCF10, DMW-BCF10E, DMW-BCF10GK, CGA-S/106C</p>

<p>Pro fotoaparáty:

Panasonic Lumix DMC-FH1, DMC-FH1GK, DMC-FH20, DMC-FH20K, DMC-FH22, DMC-FH22GK, DMC-FH3, DMC-FH3GK

DMC-FP8, DMC-FP8A, DMC-FP8G, DMC-FP8GK, DMC-FP8K, DMC-FP8N, DMC-FP8P, DMC-FP8R, DMC-FP8S, DMC-FP8V

DMC-FS10, DMC-FS11, DMC-FS12, DMC-FS12GK, DMC-FS15, DMC-FS15GK, DMC-FS25, DMC-FS25GK, DMC-FS30, DMC-FS33, DMC-FS4, DMC-FS42, DMC-FS6, DMC-FS6GK, DMC-FS62, DMC-FS7, DMC-FS7GK, DMC-FS9

DMC-FT1, DMC-FT2, DMC-FT2A, DMC-FT2D, DMC-FT2S, DMC-FT3, DMC-FT3A, DMC-FT3D, DMC-FT3R, DMC-FT3S, DMC-FT4, DMC-FT4A, DMC-FT4D, DMC-FT4K, DMC-FT4S

DMC-FX40, DMC-FX48, DMC-FX48GK

DMC-FX550, DMC-FX580, DMC-FX580GK

DMC-FX60, DMC-FX60A, DMC-FX60K, DMC-FX60N, DMC-FX60P, DMC-FX60S, DMC-FX60V, DMC-FX65, DMC-FX65A, DMC-FX65GK, DMC-FX65K, DMC-FX65N, DMC-FX65P, DMC-FX65S, DMC-FX65V, DMC-FX66, DMC-FX66A, DMC-FX66N, DMC-FX66P, DMC-FX66S, DMC-FX66V, DMC-FX68

DMC-FX70, DMC-FX70A, DMC-FX70K, DMC-FX70N, DMC-FX70P, DMC-FX70S, DMC-FX70V, DMC-FX700GK, DMC-FX700K, DMC-FX700S, DMC-FX75, DMC-FX75GK, DMC-FX75K, DMC-FX75N, DMC-FX75P, DMC-FX75S, DMC-FX75V

DMC-F2, DMC-F3, DMC-F3K, DMC-F3P, DMC-F3S

DMC-TS1, DMC-TS2, DMC-TS3A, DMC-TS3D, DMC-TS3R, DMC-TS3S, DMC-TS4, DMC-TS4A, DMC-TS4D, DMC-TS4K, DMC-TS4S</p>